

Seatpost Rack - PR-3

INSTRUCTIONS

1 The Filzer PR-3 Seatpost Rack will fit seatposts between 25 mm and 32 mm in diameter.

Warning /

- 1 Maximum load for rack is 11 kg (25 lbs), do not overload rack as this could damage the seapost and cause injury.
- 2 Do not use panniers on rack.
- 3 Do not use rack on carbon fibre seatposts.
- 1 Fit rubber shim and seatpost rack around seatpost and close the quick-release clamp around seatpost. Ensure seatpost rack is aligned properly. Adjust the tightness of the quick-release eye-bolt by turning the quick-release handle clockwise to tighten and counter-clockwise to loosen (while in the open position). Flip the quick release handle to the closed position and ensure that the rack is fixed solidly in place. If the rack is not secure on the seatpost, tighten the quick-release handle more. See Section 1.
- 2 If the quick-release eye-bolt is too short, replace it with the longer eyebolt provided. To replace eye-bolt on the quick-release lever, use two 4mm hex keys to remove the 2 bolts. Re-install the correct length eye-bolt to from quick release lever. Ensure bolts are tightened securely. See Section 2.
- 3 If too much eye-bolt is protruding from the side of the quick-release clamp you may want to use the shorter eye-bolt. Ensure that the bolt is protruding out of the quick release clamp by at least 1 mm.
- 4 Install reflector on the reflector mount. Note: reflector and hardware for reflector are NOT included. See Section 3.

