

## INSTRUCTIONS

### Warning ⚠

The workstand maximum load is 25kg (55 lbs). Do not overload the workstand or you could damage your bike and/or workstand. Ensure that the workstand is on a stable floor.

Ensure that you position/mount your bike on the workstand so the bike and stand are stable and do not fall over and cause injury or damage.


Ensure that your bike is fastened to the workstand securely so it does not move, shift or fall off and damage your bike, stand and/or property.

We recommend that you mount/clamp your bike to the workstand by your seatpost and not by your bike's frame. If you clamp the workstand to your bike frame you could crush or damage your bike frame.

Filzer is not responsible for any damage to your bike, stand, and/or property from the use of this workstand. And we are not responsible for any injury caused by the workstand.

The Filzer Workstand comes fully assembled. To unfold and use the workstand follow these steps:

### Workstand parts



### Opening Workstand

